RadioShack®

User's Guide

1201475

AM/FM
Digital Pocket Radio

Thank you for purchasing your AM/FM Digital Pocket Radio from ***RadioShack***. Please read this user's guide before using your new radio.

Package Contents

- Pocket Radio
- Wrist Strap
- User's Guide

Features

- Easy and accurate digital tuning
- Programs 20 preset stations
- Automatic scanning

RoHS COMPLIANT

Complies with the European Union's "Restriction of Hazardous Substances Directive," which protects the environment by restricting specific hazardous materials and products.

Install the Batteries



Insert 3 AAA batteries (not included), matching polarity symbols (+ and –) inside the battery compartment.

Battery Notes:

- Dispose of batteries promptly and properly. Do not burn or bury them.
- Use only fresh batteries of the required size and type.
- Replace batteries when ▭ appears. Do not mix old and new batteries, different types of batteries (alkaline or rechargeable), or rechargeable batteries of different capacities.
- If the radio will not be used for a long time, remove the batteries to prevent possible leakage.

Insert stereo earphones (not included).

Remove earphones to listen through the speaker.

AM/FM

Toggle between AM/FM bands.

PROGRAM

Press to program stations.

VOLUME +/–

Adjust volume.

Press to power on/off.



Note: FM ST appears when stereo earphones are inserted and you are receiving a station with a strong stereo signal.

Antenna

Extend for better FM reception.

TUNING ^/ v

- Press repeatedly to manually tune to stations.
- Press and hold to automatically fast tune to a radio station.

MEMORY ▼/▲

Press **MEMORY** to select a preset station or preset location.

LOCK ➡

Slide to activate locking and prevent accidental button operation. When the radio is locked, 🔒 appears.

Listen to Your Radio

1. Press ⏻ to turn on the radio.
2. Press **AM/FM** to select a radio band.
3. Press **TUNING** ^/v repeatedly to tune up/down to a station, or press and hold to automatically fast tune to a radio station.

Store Preset Stations

You can store 10 FM and 10 AM stations.

1. Press **AM/FM** to select a band and then tune to a station.
2. Press **PROGRAM**. ***PRESET*** flashes.
3. Press **MEMORY** ▼/▲ to select a preset location (0 to 9) to store the current station, then press **PROGRAM** to confirm.
4. Repeat steps 1–3 to store other presets.

Listen to a Preset Station

1. Press **AM/FM** to select a radio band.
2. Press **MEMORY** ▼/▲ to find the desired station. ***CH*** and your preset location number appears.

Listening Safely

Do not wear headphones, earphones, or earbuds while operating a motor vehicle or riding a bicycle. This can create a traffic hazard and could be illegal in some areas.

To protect your hearing:

- Do not listen at high volume levels. Extended high-volume listening can lead to permanent hearing loss.
- Set the volume to the lowest setting. Then turn on your audio device and adjust the volume to a comfortable level.
- Avoid increasing the volume. Your ears will adapt to the volume level, so a level that does not cause discomfort could still damage your hearing.

Specifications

Frequency Range.....AM: 530 ~ 1710 KHz
FM: 88 ~ 108 MHz

Power Supply ..... 3 x AAA batteries

Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.

FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your local ***RadioShack*** store or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your equipment. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Limited Warranty

RadioShack warrants this product against defects in materials and workmanship under normal use by the original purchaser for **ninety (90) days** after the date of purchase from a ***RadioShack***-owned store or an authorized ***RadioShack*** franchisee or dealer. ***RADIOSHACK*** MAKES NO OTHER EXPRESS WARRANTIES.

This warranty does not cover: (a) damage or failure caused by or attributable to abuse, misuse, failure to follow instructions, improper installation or maintenance, alteration, accident, Acts of God (such as floods or lightning), or excess voltage or current; (b) improper or incorrectly performed repairs by persons who are not a ***RadioShack*** Authorized Service Facility; (c) consumables such as fuses or batteries; (d) ordinary wear and tear or cosmetic damage; (e) transportation, shipping or insurance costs; (f) costs of product removal, installation, set-up service, adjustment or reinstallation; and (g) claims by persons other than the original purchaser.

Should a problem occur that is covered by this warranty, take the product and the ***RadioShack*** sales receipt as proof of purchase date to any ***RadioShack*** store in the U.S. ***RadioShack*** will, at its option, unless otherwise provided by law: (a) repair the product without charge for parts and labor; (b) replace the product with the same or a comparable product; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of ***RadioShack***. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

RADIOSHACK EXPRESSLY DISCLAIMS ALL WARRANTIES AND CONDITIONS NOT STATED IN THIS

LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND, IF APPLICABLE, THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, SHALL EXPIRE ON THE EXPIRATION OF THE STATED WARRANTY PERIOD.

EXCEPT AS DESCRIBED ABOVE, ***RADIOSHACK*** SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO THE PURCHASER OF THE PRODUCT OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE AND ANY LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT AND ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF ***RADIOSHACK*** HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. You may contact ***RadioShack*** at: RadioShack Customer Relations, 300 RadioShack Circle, Fort Worth, TX 76102 04/08

www.RadioShack.com

©2013. ***RadioShack*** Corporation.
All rights reserved. ***RadioShack*** is a registered trademark used by ***RadioShack*** Corporation.

Printed 06A13
in China 1201475